



4073 0901

REPAIR PARTS LIST

Key No.	Part Description	Qty.	2975PC
1	Power Cord	1	227-264-B-TSU
2	Float Switch	1	PS117-144P
3	Motor Assembly	1	**
4	Impeller	1	416-018
5	Volute	1	*
6	Suction Housing	1	772-010
7	Screw	4	670-669

* Included with Motor Assembly.

** If the motor fails, replace the pump.