



REPAIR PARTS LIST – 2800A, 3200A SERIES

Key No.	Part Description	Qty	FPSE2800A-08 115 Volt	FPSE3200A-08 115 Volt
1	Lower Volute	1	PW1-12P	PW1-11P
2	Impeller	1	PW5-13P	PW5-15P
3	Upper Volute	1	PW1-10P	PW1-10P
4	Power Cord	1	PS117-51-TSE	PS117-53-TSE
5	Automatic Float Switch	1	PS17-92	FP18-15BD

IF MOTOR FAILS, REPLACE PUMP.