

SHURFLO® LIVEWELL FILL VALVE INSTALLATION & OPERATION INSTRUCTIONS

1-1/8" BARB - MODEL: 0EM: 330-000 / AM: 330-001 3/4" BARB - MODEL: 0EM: 330-010 / AM: 330-011

FEATURES

- Adjustable flow 1/2 Turn
- Side Mount
- Nylon Construction
- 1-1/8" & 3/4" Elbow fittings
- Multi-directional
- Low Profile Design
- High Flow Capacity

■ 3 Year Warranty


TOOLS FOR INSTALLATION

- Hose clamp suitable for 3/4" or 1-1/8" depending on model.
- Nut driver or flat blade screw driver suitable for the hose clamp.
- Large pair of channel locks, pliers or crescent wrench.
- 1-3/4" Hole Saw.





- 1. Blaster Pump
- 2. Blaster Nozzle
- 3. Raw Water Strainer
- 4. High Flow Livewell Pump with Dual Inlet (washdown port)



MOUNTING INSTRUCTIONS

- **1.** Select and mark the location for the housing outlet.
- **2.** Make a 1-3/4 inch hole at the location selected.
- **3.** Remove swivel nut (#9) and mounting nut (#7) from assembly.
- **4.** Place the housing assembly (#1, #2 #3, #4, #5, #6 and #8) through the hole from inside the tank ensuring the barb fitting is outside the livewell tank.
- **5.** Thread the mounting nut (#7) onto the housing inlet (#4) from outside of the tank. Hand tighten then, 1/4 turn with wrench.
- **6.** Thread the swivel nut (#9) (hand tighten) onto the housing inlet (#4).
- **7.** Secure hose with suitable hose clamps.
- 8. Turn pump on and check for leaks.



WARNING

Do NOT operate equipment that requires 110/220 AC power while boat is in water or during installation of the SHURFLO Livewell Fill Valve.

FLOW MANAGEMENT SOLUTIONS

3545 HARBOR GATEWAY SOUTH, SUITE 103, COSTA MESA, CA 92626, (800) 854-3218 WWW.SHURFLO.COM

All Pentair trademarks and logos are owned by Pentair, Inc. All other brand or product names are trademarks or registered marks of their respective owners. Because we are continuously improving our products and services, Pentair reserves the right to change specifications without prior notice. Pentair is an equal opportunity employer.