

AUTOMATIC WATER FILLER

Help protect your pool equipment by ensuring proper water level.

Failure to keep your water level right can result in damage to pool equipment. The Pentair automatic water filler helps protect your investment by using simple, reliable float mechanisms to monitor and control the water level in your pool or spa. When water drops below a preset level, the unit meters in additional water until the proper level is restored. If water levels are too high, the built-in overflow will take the right amount of water out of the system.



AUTOMATIC WATER FILLER

Helps prevent equipment and landscape damage



Pentair automatic water fillers are the latest in automatic pool and spa water level controls. Simple and reliable, with no need for electronic controls, they ensure that your water levels are right for pool and spa operation and enjoyment.

KEY FEATURES

Side- or bottom-mounted valves

All models are available with sideor bottom-mounted plastic fill valves. Standard model can be equipped with either a side-mounted valve or a bottom-mounted Fluidmaster® Valve.

Compact design

Compact, seven-inch diameter design makes it easier to incorporate into new designs or renovations in both standard and vanishing edge pools.

ABS polymer construction

Tough, corrosion- and chemical-resistant ABS polymer construction.

Low water prevention

Prevents low water levels that can damage equipment.

Availability options

Available for standard inground and vanishing edge pools.

Color matching lid and rings

Top lid and ring available in white, black, gray, dark gray and tan. Lid assembly colors match that of all Pentair skimmers, laminars and deck jets.

Reduces overfill damage

Reduces water waste and landscape damage that can result from overfilling pool.



400 Regency Forest Dr | Cary, NC 27518 | United States | 800.831.7133 | pentair.com